Service Schematics

NOKIA 5330 Mobile TV Edition

RM-615

IMPORTANT

This document is intended for use by authorized Nokia service centers only. Please use the document together with other documents such as the Service Manual and Service Bulletins.

Version information

While every effort has been made to ensure that the document is accurate, some errors may exist. Please always check for the latest published version for this document.

If you find any errors in the document please send email to: TrainingAndVendorDevelopment@nokia.com

Version history

1.0 First Approved version.

Table of Contents

Front page	1
RAPS, HS USB, Sensors, User Interface	2
GAZOO, Audio, MMC, SIM, Battery	3
Keyboard	4
BTHFM, DVB	5
RF part	6
Component Finder Top	7
Component Finder Bottom	8

Copyright © Nokia

This material,including documentation and any related computer programs is protected by copyright, controlled by Nokia. All rights are reserved. Copying, including reproducing, modifying, storing, adapting or translating any or all of this material requires the prior written consent of Nokia. This material also contains company confidential information, which may not be disclosed to others without the prior written consent of Nokia.


MESSI(13:0)
PUSL(15:0)
BTFM(23:0)
MMC1(15:0)
DVB(6:0)
I2C1(1:0)
RFCTRL(8:0)
USB(15:0)
D2800
RAP3G$2_V4.12_PA
TOUCH_INT
DIG_AUDIO(8:0)
RFCLK(1:0)
RFCONV(11:0)
EMINT(3:0)
PCM(3:0)
AUDIOCTRL(5:0)
KEYBOARD(24:0)
INT_MMC1(13:0)
TXC(2:0)
CBUS(3:0)
ACI(7:0)
INT_SIM(5:0)
I2C2(1:0)
N2490
L2484
100nH
L2482
600R/100MHz
L2483
600R/100MHz
L2487
100nH
L2491
600R/100MHz
C2496
2u2
C2490
1/2 1u5
C2490
2/2 1u5
C2482
27p
C2481
27p
R2404
47R
R2403
47R
R2402
47R
R2401
47R
V2497
V2495
V2496
V2494
V2492
V2491
C2492
2u2
R2400
100k
VBAT_BB
VIO
GND
B3,C3,D5,E3= GND
X2491
Z2400
Z2401
VAUX
VBUS
DOCK_HS_MIC
DOCK_HS_EAR_R
DOCK_HS_PLUG_DET
DOCK_HS_GND
DOCK_HS_EAR_L
D3350
L3350
120R/100MHz
L3351
120R/100MHz
R3351
20k
VBAT
A2,D3=GND
R2802
0R
R6604
27R
R2803
27R
R2804
27R
D3000
COMBO 32Mx16 DDR
64Mx16 M3
R2890
4k7
R2891
4k7
R2893
4k7
R2892
4k7
R2490
100k
N2492
C2497
10n
VCORE
VDDCORE1
TOP_VddqS
R2025
10R
R2027
180R
R2023
17k
1k3
33R
33R
15k
J2001
J2002
J2003
2.0A
F2001
R2024
C2003
100n
N2002
C2002
100n
C2001
100n
17= GND
A11,A12,B12,B17,C17,C18,F2,G1,G2,H1,H2,J1,J2,R18,T18,U5,U17,V11,V12,V13,
YA4,YA8,YA18,YB11,YC1,YE11,YG8,YG9,YG11,YH2,YH8,YJ8,YJ13,YK7,YK12,YL11,
YL12,YM1,YM8,YM18,YN14,YP6,YU9,YU11,YU17,YV11,YV14,YH11,YA13=GND
A13,A14,A15,A16,B13,B14,B15,B16,E1,F1,R17,T17,V3,V4,V5,V6,YA7,YA14,YB1,
YB16,YF18,YH17,YK2,YK18,YL17,YL18,YT1,YV5,YV12,YV16=VIO
YA5,YB2,YB7,YB12,YB13,YB18,YF17,YK17,YL1,YL2,YM17,
YN18,YP1,YR17,YU13,YV7,YV8,YV17=VCORE


B2120
not_assembled
M2100
E2110
E2111
L2102
56nH
L2103
56nH
L2120
220R/100MHz
L2121
220R/100MHz
L2124
220R/100MHz
L2125
220R/100MHz
R2107 18V/30V
R2106 18V/30V
R2121 18V/30V
R2120 18V/30V
C2108 10n
C2135 27p
C2133 27p
C2139 10p
C2138 10p
GND
UI_EARN
UI_EARP
N2200 GAZOO_V3.5
EarP
EarN
IHFSpLP
IHFSpLN
VibraP
VibraN
SenseP
SenseM
BSI
BTemp
LST
RFTemp
WTxDet
VBatVIO
VBUSCoil
VBUSSMPSOut
CrI
CrO
LedOut
OVVLed
SetCurrD
PwrOnX
ExtPWMOut
VBUSCtrl
DP
DM
ID
Speed
SlaveSW
Suspend
MBus
MBusTx
MBusRx
HeadDet
HookDet
Mic2P
Mic2N
Mic3LP
Mic3LN
Mic3RP
Mic3RN
MicB2
VCoreCoil
VCoreCoil
VCore
XEarLC
XEarL
XEarRC
XEarR
SIMDa
SIMClk
SIMIOC
VBUS
R2082 CURRENT SENSE
R2081 47k
C2072 27p
C2081 150u_6V3
C2084 27p
C2083 10n
C2082 22u
C2249 2u2
C2232 10u
C2247 2u2
C2294 2u2
C2229 2u2
C2285 2u2
C2228 2u2
C2275 2u2
C2281 2u2
C2282 2u2
C2326 2u2
L2080 28R/100MHz
X2080
L2347 1uH
V2310
C2318 3u3
C2245 2u2
L2300 2u2H
V2300
B2200 32.768kHz
C2314 1u0
R2204 10k
SLOWAD(6:0)
LED(6:0)
EMIO(2:0)
USB(15:0)
ACI(7:0)
AUDIO(13:0)
INT_SIM(5:0)
VBAT_BB
VBAT
VCORE
L2340 1uH
C2231 22u
C2352 2u2
A2,A10,B4,B5,B8,C5,C11,D6,D15,D16,E2,F1,F7,F14,G11,G16,H4,J8,K7,K8,K11,
K13,L7,L9,L15,N12,P7,P13,P14,R4,R6,R14,R15,R16,T4,T11,T14,T15,T16=GND
A1,A14,A15,A16,B1,B9,B16,D1,D5,D7,F8,F15,H15,J15,
K15,L13,N10,N15,N16,P5,P6,P11,R7,R8,T3,T10=VBAT_BB
X2050
L2050 120R/100MHz
2.0A F2050
C2050 27p
C2051 470n
R2050
VCharIn1
VCharIn2
VCharInTest
VDDAudTx
VDDAudRx
VDDAudRx2
VDDAudRx3
VAna
VAux2
VOut
VRCP1
VCP
VRef
VBg
C2315 2u2
C2317 2u2
C2211 10u
C2165 2u2
C2267 2u2
C2271 2u2
C2268 2u2
VUSB
VMEM
VAUX1
VRFC
VR1
VBack
VR1
VRFC
VAux1
VMEM
VUSB
VRTC
FlyHigh
FlyLow
SIMDaC
C2316 2u2
C2353 2u2
C2280 2u2
C2213 2u2
C2266 2u2
C2222 2u2
C2200 27p
C2212 10n
C2319 2u2
X2302
SIMClkC
SIMRstC
VSIM
SIMCLK
SIMRST
SIMDATA
NC
TxCData
TxCClk
TxCCtrl
MicData
PMARN
EarDataL
EarDataR
PMARP
AudClk
TXC(2:0)
J2205
C2214 2u2
C3210 100n
DIG_AUDIO(8:0)
R2200 33R
C2250 10p
R2201 33R
Audio_CLK
PUSL(15:0)
SleepX
SleepClk
PURX
SMPSClk
RSTX
AUDIOCTRL(5:0)
B2100
AuxTxPDM
Data
CLK
L/R
VDD
R2103 100R
R2111 100R
VDigiMic
R2112 100R
C2269 2u2
C2136 100n
CBUS(3:0)
CBusData
CBusClk
CBusSelX
TXC_CONV(4:0)
TxCOut
AFCOut
EMINT(3:0)
EMInt
INT_MMC1(13:0)
CMDA
Data1A
Data2A
Data3A
Data4A
ClkA
ClkFB
CMDDir
Data1Dir
Data2Dir
Data3Dir
Data4Dir
X3200
L3200 600R/100MHz
C3200 100n
C3202 100p
MMC1(15:0)
DAT2
DAT3
CMD
CLK
VSS
DAT0
DAT1
Data3B
Data4B
CMDB
ClkB
Data1B
Data2B
VIO
VDD18
VIOCoil
VIOCoil
L2310 1uH
C2296 2u2
C2230 22u
DOCK_HS_GND
DOCK_HS_MIC
DOCK_HS_PLUG_DET
HeadDet
HookDet
N2101
ECI
Mic2p
Mic2n
MicBias
to ASIC
C2123 100n
C2134 100n
C2122 2u2
C2131 27p
C2132 27p
R2100 220R
MicB2
MIC2P
MIC2N
VBAT
L2100 600R/100MHz
C2125 2u2
C2127 2u2
N2100
AVDD
CPN
CPP
OUTL
OUTR
HPVSS
HPVDD
SW
SDA
SCLK
INL-
INL+
INR-
INR+
B1,C3=GND
I2C1(1:0)
C2129 2u2
C2130 2u2
C2149 2u2
C2150 2u2
L2115 3u3H
C2128 2u2
C2126 10u
DOCK_HS_EAR_L
DOCK_HS_EAR_R
Z2102
J2106
J2132



Confidential Copyright © 2010 NOKIA Only for training and service purposes


E6601
J6603
C6605 8p2
R6602 0R
C6611 68p
C6604 8p2
L6604 33nH
J6604
L6603 5n6H
L6601 15nH
GND
N6601
RFIN_U 35
VBAT 27
L6607 600R/100MHz
VBAT
GPIO_0 3
SPI_CLK 4
SPI_MISO 5
SPI_MOSI 6
SPI_IRQ 7
SPI_CS0 9
DVBH_ENA 24
VIO 21
DVB(6:0)
J6601 19 TP(IF)
23 NC
22 1.875V_TP
R6601 10k
C6601 10n
1,10,18,20,25,26,32,34,36,37,38,39,40=GND
VIO
N6615
ON C2
VOUT VIN A1 A2
VOUT VIN B1 B2
C1=GND
L6615 600R/100MHz
C6616 2u2
C6615 2u2
C6602 27p
L6003 390nH
L6002 27nH
C6007 100p
FM_ANT F1
B3 B2 D3 G2 F7 C3
C6004 15p
C6002 2u2
C6020 10n
C6005 2u2
C6003 2u2
C6011 0u47
W6020
L6020 2n7H
Z6000 2450MHz OUT IN
B1 BT_RF
C7 G7 A5 H2 A4
C6019 2u2
C6012 100n
C6001 2u2
C6006 10n
N6000
FM_RX
VDD_ANA VDD_BT_LO VDD_BT_RADIO VDD_FM VDD_DIG VDD_AUX
VDD_HOST VDD_PADS HVREGOUT_H VDD_FM_TX HVREGIN_H
A1,A2,C1,C4,D2,F2,F6,H3=GND
SYS_CLK A3
C6007 100p
RFCLKEXT
CLK_REQ(HOST_WAKE) G3 BTH_CLK_REQ 7
UART_WAKE H4 HOST_Wakeup 6
VREG_ENABLE_BST F4 BT_RESETX 0
BT_WAKEUP H6 BT_WAKEUP 5
UART_RTS E6 UART_CTS 3
UART_TX D7 UART_RX 1
UART_RX D6 UART_TX 2
UART_CTS E7 UART_RTS 4
BTFM(23:0)
I2S/PCM_CLK G5 PCM_CLK 0
I2S/PCM_IN G6 PCM_OUT 2
I2S/PCM_OUT H7 PCM_IN 3
I2S/PCM_SYNC F5 PCM_SYNC 1
PCM(3:0)
SLEEP_CLK H5 SLEEPCLK 1
PUSL(15:0)
SPKR_L E2 C6013 220n FM_AUDIO_PL 5
SPKR_R E1 C6014 220n FM_AUDIO_PR 3
FM_AUDIO_NL 6
FM_AUDIO_NR 4
AUDIO(13:0)
C6017 220n
C6018 220n



Confidential Copyright © 2010 NOKIA Only for training and service purposes



L		N		R2521	R2	V2495	R4
L2484	R4	N2492	J2	R2522	R7	V2496	Q7
L2487	R4	R		R2523	R5	V2497	Q4
L2520	R2	R2401	R6	R2524	R2	X	
L2521	R2	R2402	R6	V		X2060	H6
L2522	R7	R2403	R4	V2491	N1		
L2523	R4	R2404	R4	V2492	N10		
L2524	Q2	R2520	R2	V2494	R7		

Confidential Copyright © 2010 NOKIA Only for training and service purposes


Bottom

| | | |